

# Marine Radio Stations (source: ALRS)

## Format, Explanation

**ISTANBUL (TAH) [4360]**

The Maritime Radio Station name is followed by its call sign(s) in brackets and its four digit station identity number (SELCAL) in square brackets, if applicable. Alternative names by which a station is known may also be shown.

④	①	②	③	④	⑤	
Control Centre: 55°21'·80N 7°20'·39W		MMSI 002500100	DSC VHF MF	AMVER	OBS	Diagram page 134
Telephone: +353 74 9370103 ⑥			Fax: +353 74 9370221			
Call: Malin Head Coast Guard ⑦			Email: mrscmalin@transport.ie mrscmalinhead@irishcoastguard.ie			
NOTE(S): 1. This station does not accept commercial traffic. 2. Telemedical advice service available. 3. Weather Reports from vessels accepted; addressed OBS METEO DUBLIN. ⑧						

⑤

VHF

CALL: (Remote site name) Radio			
⑨ Glen Head	54°43'·63N 8°42'·68W	Ch 16 24 67	H24 (Ch 16)
NOTE: Ch 67 used for Safety traffic only. Direct calling on working Channels is required.			

RT (MF)	⑩	⑪	⑫
	Position	Transmits	Receives
		1644 (Ch 244)	2069

RT (HF)	⑬	⑭	⑮
	Position	Transmits	Receives
		8755 (Ch 813)	8231
			H24

Radiotelex [2301]	⑯	⑰	⑱
	Position	Transmits	Receives
		8429·5 (Ch 827)	8389·5
			H24

WT (HF)	⑲	⑳	㉑
	Position	Transmits	Receives
⑲ HLG		12935	12 MHz (3 4 5 6)
			H24

⑮

⑤ The Maritime Radio Station transmission data is divided into sections according to the services provided. The services might include any or all of the following: DSC, VHF, RT (MF), RT (HF) or Radiotelex. The Radiotelex sections include the four digit station identification number (SELCAL) in the section heading.

VHF  
RT (MF)  
RT (HF)  
Radiotelex [2301]

### Mode of Transmission

VHF indicates Very High Frequency F3E speech. RT (MF) and RT (HF) indicates Radio Telephone SSB Upper Sideband, Medium Frequency and High Frequency respectively. Radiotelex indicates F1B Narrow Band Direct Printing.

⑨ Glen Head

Where a station has remote transmitting sites, the site names and positions are given together with the appropriate frequencies.

⑲ EJM  
TAH

Call sign: Used when different call signs are allocated to different frequencies or services.

Ch 16 24 67

1644

8755

8429.5

Ⓛ

(Ch 813)

(Ch 827)

Transmit

Receives

Ⓜ

H24

1430-2030

HOURS OF WATCH: Ch 16: H24

TRAFFIC LISTS:

Ⓝ

(3 4 5 6)

## Frequency Tables

Maritime Radio Stations transmitting frequencies. If the transmitting and receiving frequencies are all the same in a table they are combined into one column. MF and HF frequencies are expressed in kHz. VHF frequencies are identified by the International maritime VHF Service Channel (Ch) designator. In the case of single sideband emissions the carrier frequency is quoted; in the case of Radiotelex Services, frequencies shown are assigned (mid-point of the F1B emissions), and care should be taken to ensure that the frequency of the suppressed carrier is set correctly, either 1.7 or 1.5 kHz below the assigned frequency, depending upon the equipment used aboard ship.

International channel numbers for RT (HF) and Radiotelex paired frequencies are shown in *italic* in parentheses. Frequency used by the radio station to transmit. Radio station receive frequency - ship transmit frequency.

The hours during which the Maritime Radio Station maintains a watch on certain frequencies. Hours are normally given either in UT (GMT) or by the use of a service symbol e.g. H24. Blank indicates hours unknown.

The frequencies used for traffic lists are shown in **bold** type. Unless otherwise stated these transmissions only occur during the hours of watch for each frequency.

WT(HF) Channels monitored by Maritime Radio Station.

# Marine Radio Stations – China

## GUANGZHOU (XSQ) [2017]

Control Centre: 23°06'96N 113°16'44E		MMSI 004123100	DSC VHF MF		OBS	Diagram page 131
Telephone: +86 20 84102403			Fax: +86 20 84428954			
Call: Guangzhou Radio			Email: gzxsq@gzrdo.com			
Telex: +85 441200 GZRDO CN						
+85 440212 GUMAT CN						
NOTE(S): Station accepts Ships' Weather Reports addressed METEO GUANGZHOU.						

### VHF

Guangzhou	23°09'00N 113°29'00E	Ch 14 16 22	H24
Huangpu	23°05'00N 113°31'00E	Ch 16 27 65	
Huangshanlu	22°47'00N 113°33'00E	Ch 16 19 22	
Zhuhai	22°25'00N 113°39'00E	Ch 16 18 23 25 61	

### RT (MF)

	Position	Transmits	Receives	Hours of Watch
		2620 2182	2182	H24

### RT (HF)

	Position	Transmits	Receives	Hours of Watch
		8782 (Ch 822)	8258	H24
		13107 (Ch 1211)	12260	
		13149 (Ch 1225)	12302	
		13182 (Ch 1236)	12335	
		17287 (Ch 1616)	16405	0900-2300
		17398 (Ch 1653)	16516	H24
		19770 (Ch 1806)	18795	
		19779 (Ch 1809)	18804	0900-2300
		19794 (Ch 1814)	18819	0600-2400
		22735 (Ch 2214)	22039	H24
		22753 (Ch 2220)	22057	0600-2400

### WT (MF)

	Position	Transmits	Receives	Hours of Watch
		500	500	H24
		445	454	On request

### WT (HF)

	Position	Transmits	Receives	Hours of Watch
		4340	4184-4184.5	On request
		8514	8359-8361	H24
		8624		On request
		12700	12446	H24
		17091		On request

### Radiotelex [2017]

	Position	Transmits	Receives	Hours of Watch
		4212 (Ch 404)	4174	2000-0800
		6316 (Ch 604)	6264.5	0800-2000
		8435 (Ch 838)	8395	H24
		12613 (Ch 1268)	12510.5	
		12648.5 (Ch 12140)	12546.5	0700-2000
		16880 (Ch 16148)	16762	0600-2400

These radiotelex services may be accessed using either [2017] Selcall or MMSI 004123100.

# Marine Radio Stations – MALAYSIA, PENINSULAR

## PENANG (9MG)

Control Centre: 5°25'58N 100°24'40E	MMSI 005330013	DSC VHF MF		OBS	Diagram page 267
Telephone: +60 4 5791921		Fax: +60 4 3907961			
NOTE(S): 1. The Radiomarine Communications Centre based at Penang Radio controls all radiomarine traffic. All the Coast Stations (including Sabah and Sarawak) listed are remotely controlled by the Control Centre and are open for traffic H24 - see separate entries for: Bintulu, Bukit Kemuning, Gunung Berinchang, Gunung Jerai, Gunung Ledang, Kota Kinabalu, Kuala Rompin, Kuala Terengganu, Kuantan, Kuching, Labuan, Machang, Permatang Pauh, Pulau Tioman and Ulu Kali. 2. Station accepts Ships' Weather Reports addressed METEO PENANG.					

## VHF

Peninsular Malaysia			
Kuantan	3°58'18N 103°25'98E	Ch 16 24	H24
Langkawi	6°20'05N 99°43'57E	Ch 16 84	
Lumut	4°12'77N 100°34'47E	Ch 16 80	
Melaka (Malacca)	2°12'00N 102°16'00E	Ch 16 63 64	
Pasir Gudang	1°26'09N 103°54'21E	Ch 16 65 79	
Penang	5°25'58N 100°24'40E	Ch 16 24	
Port Klang	2°59'00N 101°29'00E	Ch 16 24 26	

Sabah			
Kota Kinabalu	5°59'00N 116°05'00E	Ch 16 24 26	H24
Kudat	7°00'00N 116°45'00E	Ch 16 26	
Labuan	5°17'00N 115°15'00E	Ch 16 25	
Lahad Datu	5°01'00N 118°19'00E		
Sandakan	5°50'00N 118°07'00E	Ch 16 24 26	
Tawau	4°20'00N 117°55'00E	Ch 16 26 27	

Sarawak			
Bintulu	3°10′.00N 113°03′.00E	Ch 16 25 27	H24
Kuching	1°35′.00N 110°11′.00E	Ch 16 24 26	
Miri	4°26′.00N 114°00′.00E	Ch 16 25 27	
Muka	2°50′.00N 112°10′.00E		
Sibu	1°50′.00N 111°38′.00E		

The initial call should be made on Ch 16 before transferring to working frequency.

## RT (HF)

	Position	Transmits	Receives	Hours of Watch
		4414 (Ch 420)	4122	H24
		4417 (Ch 421)	4125	
		8719 (Ch 801)	8195	
		8770 (Ch 818)	8246	
		8779 (Ch 821)	8255	
		8809 (Ch 831)	8285	
		13107 (Ch 1211)	12260	
		13137 (Ch 1221)	12290	
		13152 (Ch 1226)	12305	
		17272 (Ch 1611)	16390	
		17302 (Ch 1621)	16420	

PERMATANG PAUH					
Control Centre: 5°25'10N 100°24'00E	MMSI 005330002	DSC MF		OBS	Diagram page 267
NOTE(S): 1. This station is part of the Penang (9MG) network of Coast Radio Stations. It is remotely controlled from the Radiomaritime Communications Centre at Penang. See Penang (9MG) for further information. 2. The station operates H24.					

KUANTAN					
Control Centre: 4°06'00N 103°23'00E	MMSI 005330008	DSC MF		OBS	Diagram page 267
NOTE(S): 1. This station is part of the Penang (9MG) network of Coast Radio Stations. It is remotely controlled from the Radiomaritime Communications Centre at Penang. See Penang (9MG) for further information. 2. The station operates H24.					

PULAU TIOMAN					
Control Centre: 2°48'00N 104°12'00E	MMSI 005330006	DSC VHF		OBS	Diagram page 267
NOTE(S): 1. This station is part of the Penang (9MG) network of Coast Radio Stations. It is remotely controlled from the Radiomaritime Communications Centre at Penang. See Penang (9MG) for further information. 2. The station operates H24.					

KUALA ROMPIN					
Control Centre: 2°48'00N 103°29'00E	MMSI 005330007	DSC VHF		OBS	Diagram page 267
NOTE(S): 1. This station is part of the Penang (9MG) network of Coast Radio Stations. It is remotely controlled from the Radiomaritime Communications Centre at Penang. See Penang (9MG) for further information. 2. The station operates H24.					

KUALA TERENGGANU					
Control Centre: 5°18'00N 103°08'00E	MMSI 005330009	DSC VHF		OBS	Diagram page 267
NOTE(S): 1. This station is part of the Penang (9MG) network of Coast Radio Stations. It is remotely controlled from the Radiomaritime Communications Centre at Penang. See Penang (9MG) for further information. 2. The station operates H24.					

## VHF DSC, List of Coast Stations for Sea Area A1

### MALAYSIA, PENINSULAR

station	MMSI	Position	Range	Status (Associated RCCs)
BUKIT KEMUNING	005330008	4°19'00N 103°28'00E	57	Operational (MRCC Putrajaya)
GUNUNG BERINCHANG	005330003	4°31'00N 101°23'00E	117	Operational (MRCC Putrajaya)
GUNUNG JERAI	005330001	5°47'00N 100°26'00E	95	Operational (MRCC Putrajaya)
GUNUNG LEDANG	005330005	2°03'08N 102°33'93E	95	Operational (MRCC Putrajaya)
KUALA ROMPIN	005330007	2°48'00N 103°29'00E	38	Operational (MRCC Putrajaya)
KUALA TERENGGANU	005330009	5°18'00N 103°08'00E	55	Operational (MRCC Putrajaya)
MACHANG	005330010	5°42'00N 102°17'00E	70	Operational (MRCC Putrajaya)
PULAU TIOMAN	005330006	2°48'00N 104°12'00E	27	Operational (MRCC Putrajaya)
ULU KALI	005330004	3°26'00N 101°47'00E	114	Operational (MRCC Putrajaya)

**Note** Network remotely controlled from Penang.

### MALAYSIA (Sabah)

KOTA KINABALU	005330013	6°02'00N 116°12'00E	75	Operational (MRCC Putrajaya)
LABUAN	005330014	5°17'00N 115°15'00E	22	Operational (MRCC Putrajaya)

**Note** Network remotely controlled from Penang.

### MALAYSIA (Sarawak)

BINTULU	005330012	3°13'00N 113°05'00E	48	Operational (MRCC Putrajaya)
KUCHING	005330011	1°35'00N 110°11'00E	85	Operational (MRCC Port Klang)

**Note** Network remotely controlled from Penang.

## MF DSC, List of Coast Stations for Sea Area A2

### **MALAYSIA (Sabah)**

KOTA KINABALU	005330013		N/A	Operational (MRCC Port Klang)
Remotely controlled stations:-				Operational (MRCC Port Klang)
Kota Kinabalu (MF DSC)		5°57'·00N 116°03'·00E	200	

### **MALAYSIA (Sarawak)**

KUCHING	005330011	1°35'·00N 110°11'·00E	N/A	Operational (MRCC Port Klang)
Remotely controlled stations:-				Operational (MRCC Port Klang)
Kuching (MF DSC)		1°49'·00N 109°46'·00E	200	

### **MALAYSIA, PENINSULAR**

KUALA LUMPUR	005330008	4°06'·00N 103°23'·00E	200	Operational (MRCC Putrajaya)
PERMATANG PAUH	005330002	5°25'·10N 100°24'·00E	200	Operational (MRCC Putrajaya)